

# LEMON SCENTED DISINFECTANT

## Concentrated Cleaner & Disinfectant

**Form:** Liquid

**Color:** Clear, Yellow

**Odor:** Lemon

**pH:** 11.5 – 12.5

**Solubility (in water):** Soluble  
**(in mineral spirits):** Insoluble

**VOC Content (% by weight):** <1.0

**Flash Point (ASTM D-7821):** N/A

**Specific Gravity:** 1.04 g/cm<sup>3</sup>

**Density:** 8.68 lbs/gal

**Storage Stability (at 70°F):** 1 year

<u>Ingredients</u>	<u>C.A.S. #</u>
Water.....	7732-18-5
n-Alkyl Dimethyl Benzyl Ammonium Chloride .....	68391-01-5
n-Alkyl Dimethyl Ethyl Benzyl Ammonium Chloride .....	68956-79-6
Alkylphenol Ethoxylate.....	9016-45-9
Sodium Carbonate.....	497-19-8
Tetrasodium EDTA.....	64-02-8



- | Ideal for... |   |
|--------------|---|
| •            | <b>Countertops</b>                      |
| •            | <b>Garbage Bins</b>                     |
| •            | <b>Restrooms &amp; Locker Rooms</b>     |
| •            | <b>Shower Stalls &amp; Toilet Bowls</b> |
| •            | <b>Patient Care Facilities</b>          |
| •            | <b>Operating Rooms</b>                  |
| •            | <b>Athletic/Recreational Facilities</b> |

**DIRECTIONS:**

**Disinfection:** To disinfect inanimate, hard, non-porous surfaces add 2 ounces of this product per gallon of water. Apply solution with a mop, cloth, sponge, hand-pump trigger sprayer, or low pressure coarse sprayer so as to wet all surfaces thoroughly. Allow to remain wet for 10 minutes, then remove excess liquid. For heavily soiled areas, a pre-cleaning step is required. Prepare a fresh solution for each use.

**To disinfect toilet bowls:** Flush toilet, add 2 ounces of this product directly to the bowl water. Swab the bowl completely using a scrub brush or toilet mop, making sure to get under the rim. Let stand for 10 minutes and flush.

**NOTE:** See product label for specific instructions for cleaning and decontamination against HIV-1 (AIDS) Virus, HBV and HCV on surfaces soiled with blood/body fluids.

**CONSULT PRODUCT LABEL FOR DETAILED DIRECTIONS**

HMIS				NFPA	
		Severe	4	Extreme	
Health .....	3	Serious	3	High	Health..... 3
Flammability.....	0	Moderate	2	Moderate	Flammability..... 0
Reactivity.....	0	Slight	1	Slight	Reactivity..... 0
Personal Protection.....	X	Minimal	0	Insignificant	Special Precautions.....None