

# QUICK PATCH

## Concrete Patching Compound

**Form:** Powder

**Color:** Gray

**Odor:** None

**pH:** N/A

**Solubility (in water):** Slight  
**(in mineral spirits):** Insoluble

**VOC Content (% by weight):** None

**Flash Point (ASTM D-7821):** None

**Specific Gravity:** 2.6-3.2 g/cm<sup>3</sup>

**Density:** 21.7-26.7 lbs/gal

**Storage Stability (at 70°F):** Stable

<u>Ingredients</u>	<u>C.A.S. #</u>
Silica Sand, crystalline.....	14808-60-7
Portland cement .....	65997-15-1
Gypsum .....	10101-41-4
Lime .....	1305-62-0

### Ideal for use on...

- **Concrete Highways**
- **Roads**
- **Bridge Decks**
- **Loading Docks**
- **Brick Walls**
- **Concrete Parking Lots**

### Usage Amounts

<u>Bag Size</u>	<u>Water Addition</u>	<u>Yield</u>
<b>50 lbs</b>	<b>6-7 pints</b>	<b>0.40cu.ft.</b>

**DIRECTIONS:** Prepare holes according to label directions. Place water in a clean mixer and turn on. Add **QUICK PATCH** and mix for 3-4 minutes. Transport to area to be repaired. **QUICK PATCH** should be applied within 10-20 minutes of mixing. This time will be influenced by weather conditions. To lengthen set times during hot weather—use ice-cooled water for batching—keep **QUICK PATCH** in shade—keep equipment cool by washing with cold water. Holes should be damp prior to application. **DO NOT** leave standing water. The hole should be filled by placing patch material full depth from one end of the hole to eliminate part depth lifts between batches. Consolidate material by means of hand tamping, chopping with a shovel and/or trowel. Attention to edges is particularly important. No curing membranes are required. Traffic must be kept off the patch for one (1) hour.

<b>HMIS</b>			<b>NFPA</b>		
	Severe	4	Extreme		
Health .....	Serious	3	High	Health.....	1
Flammability.....	Moderate	2	Moderate	Flammability.....	0
Reactivity.....	Slight	1	Slight	Reactivity.....	0
Personal Protection.....	Minimal	0	Insignificant	Special Precautions.....	None