

OVEN CLEANER

Oven & Grill Cleaner Spray

Form: Aerosol Liquid

Color: Clear, colorless

Odor: Slight solvent

pH: 12-13

Solubility (in water): Soluble
(in mineral spirits): No data available

VOC Content (% by weight): 9%

Flash Point: None (Liquid Portion)

Specific Gravity: 1.0 g/ml

Density: 8.35 lbs/gal

Storage Stability (at 70°F): 1 year

<u>Ingredients</u>	<u>C.A.S. #</u>
Sodium Hydroxide	1310-73-2
Glycol Ether EB	111-76-2
Propane	74-98-6
Isobutane	75-28-5
2-aminoethanol, ethanolamine.....	141-43-5

Use As A...

- **Grill Cleaner**
- **Broiler Cleaner**
- **Deep Fryer Restorer**
- **Burner Cleaner**
- **Pot and Frying Pan Cleaner**
- **Smokehouse Cleaner**

DIRECTIONS FOR USE:

1. Wear rubber gloves.
2. For gas ovens – DO NOT SPRAY ON PILOT LIGHT.
3. Use in either warm (200°F) or cold empty oven. Clean rack separately. Spread newspapers under oven door.
4. SHAKE CAN WELL. With can upright, point valve opening toward the surface to be sprayed and away from eyes. Spray oven surfaces from a distance of 9 to 12 inches.
5. Allow gel to work 5 to 10 minutes on warm surfaces, 10 to 20 minutes on cool surfaces. Then wipe clean with a wet cloth, sponge, or paper towels. Rinse oven thoroughly with potable water.
6. For heavily encrusted areas, repeat application, using steel wool or soap pad.
7. Pre-heat oven for 10 minutes before next use.

HMIS®			NFPA®		
Health	2	Severe 4	Extreme	Health	2
Flammability.....	4	Serious 3	High	Flammability.....	4
Reactivity.....	0	Moderate 2	Moderate	Reactivity.....	0
Personal Protection.....	X	Slight 1	Slight	Special Precautions.....	None
		Minimal 0	Insignificant		